

## HAND PROTECTION

## UNDERSTANDING THE EN MARKINGS



#### **EN388 Mechanical Risks**

Four tests are conducted, namely Abrasion resistance, Cut resistance, Tear resistance and Penetration, and the results are shown as a performance score ranging from 1 - 4 with Cut 1 - 5. The higher the score the bet ter the test performance, an example being 6631 009 Unipur PU Handler with a score of 4 1 4 1 which of fers maximum abrasion, low cut, maximum tear and low penetration. By comparison, a 6049 409 Helix C5 Glove with 4 5 4 2 score, offers highest abrasion, highest cut, highest tear and higher penetration resistance. Clearly this is a far superior glove.



# EN374-2 Liquid proof

This tests with air and water for pinholes to determine whether liquid proof. If yes, the standard will be marked on the glove together with the pictogram shown here. Note that this is for water, not chemicals.



## **EN374- 3 Permeation by Chemicals**

This tests the breakthrough time of a chemical through the glov e. Three chemicals from the list of 12 are selected, and no permeation through the glove wall must occur after a minimum of 30 minutes. The 12 chemicals embrace the major chemical groups and are listed as: A- Methanol, B- Acetone, C- Acetonitrile, D- Dichloromethane, E- Carbon Disulphide, F- Toluene, G- Diethylamine, H- Tetrahydrofurane, I- Ethyl Acetate, J- N-heptane, K- Sodium Hydroxide 40%, and L- Sulphuric Acid. To carry this symbol, EN374-2 must be passed. By way of example, a glove tested for permeation with Dichloromethane, Toluene and Sulphuric Acid 40% would be marked EN374 DFL together with the pictogram shown. The glove is a true chemical resistant glove for the named chemicals.



www.uvex.co.za

Code	Description	Sizes*	Length	Packing & Price Breaks	EN388 Mechanical	EN374-3 Chemical	alle	مالم
	Helix Climatec Gloves: The Uvex Profas Bamboo TwinFlex® technology gives superior cut resistance.  Outer layer is made from fibreglass & polyamide; then bamboo rayon & Dyneema® inner for comfort and additional cut protection; then palm & finger dipped in HPE SoftGrip foam. Not for high heat conditions.						* [ 20]	
	Helix C3 - Cut level-3 protection. Available early 2010						and the second	Separate Sep
6054 209	Helix C3 Wet - wet & oily conditions	7 - 11	27cm	1 or 10	4342			
6054 409	Helix C3 Foam - dry conditions	7 - 11	27cm	1 or 10	4342			
6054 509	Helix C3 Carbon ESD - electrostatic discharge properties	7 - 11	27cm	1 or 10	4343		6054 409 Helix C3	6049 209 Helix C5
	Helix C5 - Highest cut level-5 protection						offe	990
6049 209	Helix C5 Wet - wet & oily conditions	7 - 10	27cm	1 or 10	4542			ATT
6049 409	Helix C5 Foam - dry conditions	7 - 10	27cm	1 or 10	4542		MEELO	
	Polyurethane Dipped Gloves - non-sweat handler with maximum feel						U	_10
6631 009	Unipur PU Grey - grey nylon liner	6 - 11	22cm	10 or 100	4141		UVEX COL ( mark)	MARIE MODEL
	Nitrile Dipped Gloves - superior fo	eel and	oil resis	stance.				
9850 009	Uniflex Nitrile Yellow - Knit-wrist, palm coated	7 - 10	22cm	12 or 144	4121		6631 009 Unipur PU	6600 009 Unilite Nitrile
9860 009	Uniflex Nitrile Yellow - Knit-wrist, fully coated	7 - 10	22cm	12 or 144	4121		ompar 10	
6600 009	Unilite Nitrile Grey - white nylon liner	7 - 10	25cm	12 or 144	4131			.000
6634 009	Unipur Nitrile Grey - grey nylon liner	6 - 10	22cm	10 or 100	4133			43301
1860 009	Compact Nitrile Blue - Knitwrist cuff on brushed jersey liner	9 - 10	27cm	12 or 144	4221		A COLOR	
1960 009	Compact Nitrile Blue - Straight cuff on brushed jersey liner	9 - 10	27cm	12 or 144	4221		a uvex	
3960 010	Compact Nitrile Plus - Knitwrist cuff on reinforced terrycloth palm	10	27cm	12 or 144	4241			Jan 20 Cam
	Nitrile & Neoprene Gloves - unsupported liquid handling							
3304 009	Profastrong Green - nitrile chemical & solvent resistant	7 - 10	33cm	10 or 100	4101	AJKL	3304 009 Profastrong	3307 009 Profapren
3307 009	Profapren Navy - neoprene oil & chemical resistant	7 - 11	33cm	10 or 100	3131	AKL	M.	.1f1
	Cut and Chemical Gloves - multi-layer construction							
2724 009	Protector Chem - cut and liquid protection	9 - 10	27cm	1 or 10	3 4 4 2	AJKL		LUVEN
4020 009	Protector Chem - longer as above	9 - 10	40cm	1 or 10	3 4 4 2	AJKL	Other Comments	Ca Speed
6627 009	Latex Dipped Gloves Unigrip Green - heavy duty handler, knitted cotton liner. Not for oil	7 - 10	20cm	12 or 144	2142		2724 009 Protector	6627 009 Unigrip

**Notes:** \* Sizes shown are those manufactured, and some are subject to special import and minimum quantities. \*\* Data sheets for each glove available on enquiry. Specifications subject to change without notice. The last two digits in the code describe size only. Helix®, Climatec®, Climazone® & Twinflex® are Uvex brands. Dyneema® is a DSM brand.